



Lighting the World since 1908

Anti-Flicker Ring for Aladdin Model 23 Burner

Installation Instructions

1. Remove gallery and raise wick about ¼" above wick tube.
2. Place disc over wick so it is on top of the outer wick tube.
3. Replace gallery and lock down tight.
4. Remove gallery. Disc should be pressed into inner cone of the gallery.
If it is not, it will still work, but you will need to remove and replace the disc when cleaning the wick.
5. Look down thru the center hole in the top of the gallery to be sure the disc is below the row of holes at the top of the inner core.
6. Light lamp. When the wick is fully lit, turn it down very low(to avoid roughing the top of the wick when replacing gallery). Replace gallery. Operate lamp as you normally would.

The Trademarks Aladdin and Lox-On are used under license from Aladdin Industries LLC